

## Emergency control for automatic door opener



**SKU**

RZ-20154-ST

**Produkt Verfügbarkeit**

**Breite/width**

**Tiefe/depth**

**Höhe/height**

**HE/U**

**Länge/length**

**kW**

Control unit for automatic door opener: RZ-20154

In case of failure or malfunction of the air conditioner, the doors open automatically - see RZ-20154! The controller follows a temperature measurement. The threshold values (maximum temperature) can be set locally. By default the threshold at 35°C is set.